# FireProtect 2 AC (Heat/CO) Jeweller

Wireless mains-powered heat, and carbon monoxide detector

Compatibility	Control panels Hub Plus Hub 2 (2G) Hub 2 (4G) Hub 2 Plus Hub Hybrid (2G) Hub Hybrid (4G)  Range extenders ReX ReX 2
Communication	Jeweller communication technology
	Proprietary wireless communication technology to transmit commands, alarms, and events.  Key features:
	Maximum effective radiated power (ERP) up to 20 mW Automatic power control to reduce power consumption and noise interference.  Radio signal modulation GFSK  Radio signal range
	up to 1,700 m up to 5,500 ft Between detector and hub (or range extender) in an

	open space.
	Encrypted communication All stored and transmitted data are protected by block encryption featuring a dynamic key.
	Frequency hopping Radio communication uses frequency hopping to prevent interception and jamming.
Sensitive elements	heat sensor CO (carbon monoxide) sensor
Dangerous temperature detection	Sensitive element according to the requirements for Class A1 heat detectors Requirements of EN 54-5 and BS 5446-2 standards.
	High temperature alarm at temperatures above 64 °C at temperatures above 147 °F
	Temperature spike alarm when the temperature rises by more than 10 °C 50 °F in 1 minute or less
Carbon monoxide (CO) detection	Sensitive element chemical CO sensor
	Alarm if accumulated dose of CO is exceeded over 50 ppm (0.005%) — in 90 minutes or less over 100 ppm (0.01%) — in 40 minutes or less over 300 ppm (0.03%) — in 3 minutes  CO concentration exceeding 400 ppm (0.04%) within a span of 3 hours poses a life-threatening risk. The detector will cease notifications regarding hazardous carbon monoxide levels once the concentration decreases to 50 ppm (0.005%) within a 1-minute duration.
	Sensor service life 10 years After 10 years of operation, the detector must be replaced with a new one.
Additional features	Built-in siren volume 85 dB at a distance of 3 meters volume 85 dB at a distance of 9 ft

#### Interconnected fire detectors alarms

# via primary interconnection

If one of the fire detectors in the system detects a threat, it sends an alarm to the hub. Within 20 seconds, the hub initiates an interconnected alarm and sends data to Ajax apps.

#### via fallback interconnection

At the same time with notifying the hub, the initiating detector sends an alarm directly to other detectors. All connected detectors activate the buzzer within a minute. It will work even in the worst-case scenario of losing connection with the hub.

## **LED** indication

## green is a power indication

An LED indicator on the device enclosure lights continuously when powered by an external power source. If the device draws power from the backup battery, the LED indicator lights up once every 56 seconds. This indication complies with the requirements stipulated in EN 14604 and EN 50291 standards.

# yellow is a malfunction indication

An LED indicator on the device enclosure lights up to signal detected malfunctions. This can occur in instances such as battery depletion, smoke chamber contamination, or reaching the end of the service life.

## red is a fire alarm indication

An LED indicator on the device enclosure lights up when the detector registers a fire alarm.

## Button on the front panel of the detector

In normal mode, pressing the button initiates the smoke chamber test. In the event of an alarm or malfunction, pressing it turns off the detector sound notification.

## **External power supply**

110-240 V~, 50/60 Hz

The phase and neutral cables from the external power supply should be connected to the WAGO terminals on SmartBracket mounting panel. To remove the detector from SmartBracket, there is no need to disconnect the power cables.

#### Recomendations

The device is designed for indoor installation only. SmartBracket mounting panel allows adjusting the

	position of the detector even after installation.
Sabotage protection	Tamper alarm  Notifications on attempts to detach the detector from the surface or remove it from the mounting panel.
	Protection against spoofing device authentication
	Communication loss detection within 15 minutes The time required to detect a communication loss depends on the settings for the number of undelivered data packages (specified in the Jeweller or Jeweller/Fibra settings).
Power supply	Main 110-240 V~, 50/60 Hz Up to 2 W of mains power consumption.
	Backup 1 non-replaceable lithium battery Allows the detector to operate autonomously without the main power source.
Enclosure	Dimensions 122 × 122 × 54 mm 4.80" × 4.80" × 2.13"
	<b>Weight</b> 305 g 10.76 oz
	Operating temperature range from 0 °C to +50 °C from 32 °F to 122 °F
	Operating humidity up to 80%
Colours	Black White
Complete set	FireProtect 2 AC (Heat/CO) Jeweller SmartBracket mounting panel WAGO 221 3-conductor terminal — 2 pcs. (pre-installed in SmartBracket) Installation kit Quick start guide
Warranty	24 months
Service life	10 years